


Sony Mavica FD88 Checklist

1. Battery charged (underneath)
2. Disk In (side)
3. Lens cap off (front)
4. Selector to "STILL"
5. Power on
6. Image size "640"
7. Quality "Fine"
8. Macro on



How do you get sharp pictures like those in the picture of the week?



1. Use the Mavica FD-88, many offices have two almost identical digital cameras an FD-81 or 83 and the FD-88 that came with this project.
2. Use the macro setting on the Mavica FD-88. If you are taking close-ups and don't see the little flower icon on the view screen the macro setting is not on.
3. The macro setting won't work if you are in manual focus mode (switch on side of camera). It also won't work if you are already zoom-ed in on the sample.
4. Get close, that's what the macro is for. With the macro setting on you can get the lens within an inch of the sample and have it still be in focus.
5. Hold the camera still and press the button halfway down (the camera will automatically double-check the focus and exposure) it will tell you when it is ready to take the picture when the green dot on the display quits blinking, then push the button the rest of the way.